

AMERICAN AUDIO®

DCD-PRO310 MKII

Professional Dual CD Player

USER MANUAL



FOR BEST CD-R DISC PLAYBACK RESULTS IN THIS CD PLAYER PLEASE FOLLOW THESE GUIDE LINES:

1. High quality CD-R Audio discs (should conform to the standards of the Orange Book 2).
2. Use a high quality bit rate when recording discs (At least 160kbps).
3. Record discs in the slowest speed possible (i.e. 2x or 4x speed).

***Please Note:** All specifications and improvements to and in the design of this unit and this manual are subject to change at any time without any prior written or published noticed.*


For service parts visit <http://parts.americandj.com>

AMERICAN AUDIO®
6122 S. Eastern Ave
Los Angeles Ca. 90040
www.americanaudio.us

TABLE OF CONTENT

Electrical Safety Precautions	4
Important Safety Instructions	7
Product Information	10
Set-Up	12
Main Features	13
General Functions and Controls	14
Basic Operations	20
Time Bar Indicator	22
Using the Pitch Slider Percentage Selector (8)	22
(+) Pitch Bend button (14)	24
(-) Pitch Bend button (14)	24
Jog Wheel (1)	24
Flip-Flop (Relay) Connection and Setup	27
Before Switching off the Power	28
Compact Disc	29
ROHS – A Great Contribution to the Conservation of Environment	30
WEEE – Waste of Electrical and Electronic Equipment	31
Specifications	32

Electrical Safety Precautions



The lightning flash with an arrow triangular symbol is intended to alert the user to the presence of non-insulated “dangerous voltage” within the product’s enclosure, and may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point triangular symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the user manual accompanying the unit.


	<p style="text-align: center;">CAUTION</p> <p style="text-align: center;">RISK OF ELECTRIC SHOCK! DO NOT OPEN!</p> <p style="text-align: center;">TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER (OR BACK). THERE ARE NO USER SERVICEABLE PARTS INSIDE. REFER SERVICE TO YOUR AUTHORIZED AMERICAN AUDIO® SERVICE TECHNICIAN.</p>	
--	---	--

	<p>Please carefully read and understand the instructions in this manual thoroughly before attempting to operate this unit. These instructions contain important safety information regarding the use and maintenance of this unit. Take special care to follow all warning symbols and labels both on the unit and printed in this manual. Also, Please keep this manual with the unit, for future reference.</p>
--	---

CAUTION:

- Handle the power supply cord carefully. Do not damage or deform; it may cause electric shock or malfunction when used. Hold the plug attachment when removing from wall outlet. Do not pull on the cord.
- To avoid electric shock, do not open the top cover when the unit is plugged in. If problems occur with the unit, call your local American Audio® dealer.

- Do not place metal objects or spill liquid inside the unit. Electric shock or malfunction may occur.
- The serial and model number for this unit is located on the rear panel. Please write down the numbers here and retain for future reference.
 - Model No. _____
 - Serial No. _____

	<p>CAUTION:</p> <p>TO PREVENT ELECTRIC SHOCK DO NOT USE THIS (POLARIZED) PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE CAREFULLY INSERTED TO PREVENT BLADE EXPOSURE!</p>	
---	--	---

CAUTION:

- USE OF CONTROLS OR ADJUSTMENTS OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE
- THE DEVICE SHOULD NOT BE ADJUSTED OR REPAIRED BY ANYONE EXCEPT PROPERLY QUALIFIED SERVICE PERSONNEL.

<p>NOTE:</p> <p>This product satisfies FCC regulations when shielded cables and connectors are used to connect the unit to other equipment. To prevent electromagnetic interference with electrical appliances such as radios and televisions, use shielded cables and connectors for connections.</p>	<p>NOTE:</p> <p>This device uses a semiconductor laser. It is recommended for use in a room at the following temperature: 41° - 95°F or 5°C - 35°C.</p>
---	--



WARNING:

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT
EXPOSE THIS DEVICE TO WATER OR MOISTURE!



NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the unit into an electrical outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IMPORTANT SAFETY INSTRUCTIONS

Read Instructions – All the safety and operating instructions should be read before the product is operated.

Retain Instructions – The safety and operating instructions should be retained for future reference.

Heed Warnings – All warnings on the product and in the operating instructions should be adhered to.

Follow Instructions – All operating and use instructions should be followed.

Cleaning – The product should be cleaned only with a polishing cloth or a soft dry cloth. Never clean with furniture wax, benzene, insecticides or other volatile liquids since they may corrode the cabinet.

Attachments – Do not use attachments not recommended by the product manufacturer as they may cause hazards.

Water and Moisture – Do not use this product near water — for example, near a bathtub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like.

Accessories – Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

Cart – A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.



Ventilation – Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

Power Sources – This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company.


Location – The appliance should be installed in a stable location.

Nonuse Periods – The power cord of the appliance should be unplugged from the outlet when left un- used for a long period of time.

Grounding or Polarization

- If this product is equipped with a polarized alternating current line plug (a plug having one blade wider than the other), it will fit into the outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.
- If this product is equipped with a three-wire grounding type plug, a plug having a third (grounding) pin, it will only fit into a grounding type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding type plug.

Outdoor Antenna Grounding – If an outside antenna or cable system is connected to the product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges.



Article 810 of the National Electrical Code, ANSI/NFPA 70, provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

See **Figure 1**.

Power Cord Protection – Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

Lightning – For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.

Power Lines – An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

Overloading – Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

Object and Liquid Entry – Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

Servicing – Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

Damage Requiring Service – Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- When the power supply cord or plug is damaged.
- If liquid has been spilled, or objects have fallen into the product.
- If the product has been exposed to rain or water.
- If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
- If the product has been dropped or damaged in any way.
- When the product exhibits a distinct change in performance - this indicates a need for service.

Replacement Parts – When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.

Safety Check – Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

Wall or Ceiling Mounting – The product should not be mounted to a wall or ceiling.

Heat – The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

PRODUCT INFORMATION

GENERAL INFORMATION

- The device should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
- Do not let insecticides, benzene, or thinner come in contact with the surface of the unit.
- Never disassemble or modify your unit in any way, doing so will void your manufacturer's warranty.
- Never plug this unit in to a dimmer pack.
- Do not attempt to operate this unit if it becomes damaged in any way.
- This unit is intended for indoor use only, use of this product outdoors voids all warranties.
- Always mount this unit in a safe and stable manner.
- Disconnect from main power before making any type of connection.

This unit has been thoroughly tested and has been shipped in perfect operating condition. Carefully check the shipping carton for damage that may have occurred during shipping. If the carton appears to be damaged, carefully inspect your unit for any damage. Be sure all accessories needed to operate the unit have arrived intact. In the event damage has been found or parts are missing, please contact our toll free customer support number for further instructions. Please do not return the unit to your dealer without first contacting customer support.

CLEANING INFORMATION

The CD player should be cleaned only as recommended by the manufacturer. Use a soft cloth to wipe down the outside of the unit. For stubborn stains moisten a soft cloth with glass cleaner or other mild detergent to wipe away any stains. Use a soft cloth to wipe any residual cleaner. Never use volatile cleaners such as benzene, solvent, or thinner to clean your unit, these cleaners will damage the unit's surface.

The pick-up lens should not become dirty under normal usage. If the lens does become dirty, contact American Audio Technical Support for further instructions. Third party lens cleaners are available but not highly recommended. Use of some of these cleaners may damage the pick-up lens, be sure to follow extreme caution when using these types of cleaners.

LINE VOLTAGE SELECTION

- The desired voltage may be set with the *Voltage Selector Switch* on the rear panel (using a flat head screw driver).
- Do not force the *Voltage Selector Switch* as this may cause damage.
- If the *Voltage Selector Switch* does not move smoothly, please contact a qualified service technician.

CUSTOMER SUPPORT

American Audio® provides a toll free customer support line, to provide set up help and to answer any question should you encounter problems during your set up or initial operation.

You may also visit us on the web at www.americanaudio.eu for any comments or suggestions.

For service related issue please contact American Audio®.

Service Hours are Monday through Friday 9:00 a.m. to 5:00 p.m. Pacific Standard Time.

Voice: (800) 322-6337

Fax: (323) 582-2941

E-mail: support@americanaudio.eu

Warning! To prevent or reduce the risk of electrical shock or fire, do not expose this unit to rain or moisture.

Caution! There are no user serviceable parts inside this unit. Do not attempt any repairs yourself; doing so will void your manufactures warranty. In the unlikely event your unit may require service please contact customer support. Please do not return to your dealer without first contacting customer support.

SET-UP

CHECKING THE CONTENTS

Be sure your DCD PRO310 MKII™ was shipped with the following:

- DCD-PRO310 MKII™ Dual CD player unit
- Operating Instructions (this booklet)
- DCD-PRO310 MKII™ Controller Head Unit
- Dual Male to Male RCA cable

INSTALLING THE UNITS

- Place your unit on a flat surface or mount it in a secure rack mount case.
- Be sure the player is mounted in a well-ventilated area where it will not be exposed to direct sunlight, high temperatures, or high humidity.
- Try to place the unit as far as possible from TVs and tuners, as the unit may cause undesirable interference.

CONNECTIONS

- Be sure main power is connected last to prevent any electrical damage.
- **AUDIO CONNECTIONS:** Use the included RCA cable to connect the outputs of the device to the line inputs of a mixer. Never connect a CD player's output to a mixers "phono" inputs.


CAUTION: Be sure to use the supplied control cables. Using a different type of cable may result in unit damage. To avoid severe unit damage, be sure main power is off when connecting the control cables.

CAUTION

To avoid severe damage to the unit, be sure the power is off when making connections to the unit.

CAUTION

The player will work normally when the main unit is mounted with the front panel within 15 degrees of the vertical plane. If the unit is tilted excessively, disks may not be loaded or unloaded properly.



MAIN FEATURES

- 8 times over sampling 1 bit D/A converter
- Auto Cue
- 60 Second Transport Protection (*)
- Pitch Control and Bend (+/-4%, +/-8%, +/-16%)
- Jog Wheel Pitch Bend (**)
- Single or Continuous Play
- Selectable Time Display
- Flip Flop™ (Relay Playback) (***)
- Pitch Display
- Reads CD and CD-R Media
- Repeat in Single Mode
- 4 Speed Search
- 10+ Track Skipping

(*) 60 Second Transport Protection: The CD transport tray will automatically close if left open for more than 60 seconds. If a CD is left in the tray it will immediately cue.

() Jog Wheel Pitch Bend:** During normal playback, the jog wheel acts as a momentary pitch bend. Turning the wheel in a clockwise direction will increase the speed and turning the wheel in a counter-clockwise direction will decrease the speed.

(*) Flip-Flop™:** For FLIP-FLOP™ results you must use both drives. Connect your device as described in the set-up section of this manual. This feature will start the next player side once one player side has ended. For example, if drive one is playing and it ends, drive two will instantly begin to play. You may set FLIP-FLOP™ to play track to track or music source device to music source device.

GENERAL FUNCTIONS AND CONTROLS

REMOTE CONTROL - FRONT




Figure 3

(1) Jog Wheel – The jog wheel serves two functions depending on the current operating mode:

- The jog wheel will act as a slow frame search control when the unit is in pause or cue mode, allowing you to set a specific cue point or find a particular starting point.
- The inner wheel also works as a momentary pitch bend during playback. Turning the wheel clockwise will increase the pitch percentage up to 16%, and turning the wheel in the counterclockwise direction will decrease the pitch percentage up to -16%. The pitch bend will be determined on how fast you turn the wheel.

(2) Liquid Crystal Display (LCD) – This high quality LCD indicates all the functions (play, pause, cue, etc.), as they occur. This display is viewable at several comfortable angles as described on page 18 (Liquid Crystal Display (LCD)). The LCD icons will be described in the next section.

(3) Pitch Slider – This slider is used to adjust the playback pitch percentage when the pitch function (13) is activated. The slider is a set adjustment and will remain set until the pitch slider is moved or the pitch (13) function has been turned off. The maximum pitch range of the slider is +/-16%. This adjustment can be made with or without a CD in the drive. The pitch adjustment will remain even if a disc has been removed, and will reflect on any other disc loaded into the unit. That is to say, if you set a +2% pitch on one disc, remove that disc and insert another, that disc will also have a +2% pitch. The amount of pitch being applied will be displayed in the LCD (2). Use this slider to match the BPM's of this unit to that of another music source. By changing the pitch of one disc with respect to the other in this way, the beats can be matched.

(4) Loop IN Button – This function allows you to set a Cue Point (see page 21 (Setting Cue Points) without music interruption (“Cue on the fly”). This button also sets the starting point of a loop (see page 25 (Creating and Playing a Loop)).

(5) Repeat Button – When the player is in *Single* mode and this button is pushed, the song will repeat until the button is pressed again. The red LED above the button will glow when this function is active.

(6) +10 Track Skip – This button allows you to skip ahead by 10 tracks. **Example:** *if you are at Track #1, pressing this button will skip you to Track #11, press the button again, it will skip to Track #21. If there are not that many tracks, it will go back to Track #1.*

(7) SGL/CTN – This button allows the unit's play mode to change between *Single* and *Continuous*. In single mode the unit will play a single track and return to cue mode. In continuous mode the unit continues to play track by track and returns to cue mode after all tracks have played.

(8) Pitch Percentage Selector – Choose from pitch percentages of 4%, 8%, and 16%. See page 22 (Pitch Adjustments) for more details.

(9) Time – The *Time* button is used to change the displayed time values. Time can be displayed as *Elapsed Track Time*, *Remaining Track Time*, and *Total Disc Remaining Time*.

(10) Track Buttons –

-  Track Button – This button is used to select your desired track. Tapping this button will forward skip to the next track, holding down this button will rapidly forward skip through the tracks on your CD.
-  Track Button – This button is used to select your desired track. Tapping this button will skip backward to the previous track, holding down this button will rapidly skip backward through the tracks on your CD.

(11) Loop OUT Button – This button is used to set the ending point of a loop. A loop is started by pressing the *IN* button (4), pressing the *OUT* button sets the loop ending point. The loop will continue to play until the *OUT* button is pressed once again.

(12) Relay Button – This button is acitvates Flip-Flop™ mode. See page 27 (Relay (FLIP-FLOP™)) for more information.

(13) Pitch Button – This button is used to turn the pitch function on and off. The pitch functions of the Pitch Slider (3), Pitch Bend Buttons (14) and Jog Wheel (1) will not function without this function being activated. The pitch slider and "+" and "-" pitch bend buttons have a maximum range of +/-16%.

(14) Pitch Bend Buttons –

- **(-) PITCH BEND** – The (-) pitch bend function creates a momentary “Slow Down” in the CD’s pitch speed (Beats per minute - BPM) when the Pitch **(13)** function is activated. This function allows the beats between two CD’s or any other music source to match. This is a momentary function. When the button is depressed the pitch speed will automatically return to the Pitch Slider’s **(3)** selected pitch. Holding down this button will give a maximum of -16% pitch. Be sure to remember that this function is a momentary pitch adjustment, for a more precise adjustment use the Pitch Slider **(3)** to match the BPM’s with another playing music source.
- **(+) PITCH BEND** – The (+) pitch bend function creates a momentary “BUMP” in the CD’s pitch speed (Beats per minute - BPM) when the Pitch **(13)** function is activated. This function allows the beats between two CD’s or any other music source to match. This is a momentary function. When the button is depressed the pitch speed will automatically return to the Pitch Slider’s **(3)** selected pitch. Holding down this button will give a maximum of +16% pitch. Be sure to remember that this function is a momentary pitch adjustment, for a more precise adjustment use the Pitch Slider **(3)** to match the BPM’s with another playing music source.

(15) SEARCH BUTTONS

-  This search button allows you to quickly scan backwards through a track.
-  This search button allows you to quickly scan forwards through a track.

(16) ReLoop Button – If a loop has been made (see page 25 (Creating and Playing a Loop), but the CD Player is not actively in *Loop* mode (a loop is not playing), pressing the *ReLoop* button will instantly reactivate the *Loop* mode. To exit the loop, press the Loop OUT Button **(11)**.

(17) PLAY/PAUSE BUTTON – Each press of the Play/Pause button causes the operation to change from play to pause or from pause to play. While in play mode, the green play LED will glow, and while in pause mode, the green play LED will flash.

(18) CUE – Pressing the CUE button during playback immediately pauses playback and returns the track to the last set cue point. The red Cue Button LED will glow when the unit is in cue mode. The LED will also flash every time a new Cue Point is set. The CUE button can also be held down to momentarily play the CD. When you release the CUE button it instantly returns to the last set Cue Point.

(19) OPEN/CLOSE (Disc Tray Open/Close) – This button is used to open and close the disc transport tray door. **NOTE:** *When a disc is loaded, the tray will not open unless the unit is in pause or cue mode.*

REMOTE CONTROL – REAR




Figure 4

(20) REMOTE JACK – Connect the supplied 8 pin din cable from this jack to the player's remote connector. This will allow you to control the player functions.

PLAYER UNIT (FRONT)




Figure 5

(21) DRIVE 1 Transport Tray - This tray is used to load and unload a compact disc into the drive 1 mechanism. The tray is opened and closed by pressing the Drive 1 OPEN/CLOSE button (22). Never attempt to force the transport tray open or close when the power is turned off.

(22) DRIVE 1 OPEN/CLOSE (Transport Tray Open/Close) - This button is used to open and close the Drive 1 transport tray. **NOTE:** When a disc is already loaded in the transport tray, the tray will not open unless the unit is in pause or cue mode.

(23) POWER SWITCH - This switch is used to control the unit's main power. A red LED directly above the power switch will glow to indicate main power is active.

(24) DRIVE 2 OPEN/CLOSE (Transport Tray Open/Close) - This button is used to open and close the Drive 2 transport tray. **NOTE:** When a disc is already loaded in the transport tray, the tray will not open unless the unit is in pause or cue mode.

(25) DRIVE 2 Transport Tray - This tray is used to load and unload a compact disc into the Drive 2 mechanism. The tray is opened and closed by pressing the Drive 2 OPEN/CLOSE button (24). Never attempt to force the transport tray open or close when the power is turned off.

PLAYER UNIT (REAR)




Figure 6

(26) DRIVE 1 AUDIO OUT R & L - These jacks send a left and right analog mono output signal. Use these jacks to send standard audio to a mixer or receiver. The red colored jack represents the right channel output and the white jack represents the left channel's output.

(27) REMOTE JACK - Connect the supplied 8 pin cable from this jack to the remote control's connector. This will allow you to control the player functions with the remote unit.

(28) POWER CONNECTOR - This is the main power connection. Only use the supplied polarized power cord. Use of any other power may result in severe damage to the unit. Be sure the local power matches the unit's required power.

(29) Voltage Selector – Because power supplies vary from location to location a voltage selector switch has been incorporated in the unit's design. This switch can select a voltage input of 115V or 230V to accommodate the two major power sources. Always be sure to disconnect the power plug before changing the voltage. Only dual voltage units have this switch.

(30) DRIVE 2 AUDIO OUT R & L - These jacks send a left and right analog mono output signal. Use these jacks to send standard audio to a mixer or receiver. The red colored jack represents the right channel output and the white jack represents the left channels output.

LIQUID CRYSTAL DISPLAY (LCD)




Figure 7

(31) Time Bar Indicator – This bar visually details the time defined in the *Time Meter (36, 37, & 38)*. As with the *Time Meter (36, 37, & 38)*, this bar is also dependent on the selected time function *Remain (35)*, *Elapsed*, or *Total Remain (34)*. This bar will begin to flash when 15 seconds of a track remain and will begin to rapidly flash when 3 seconds of a track remain. The flashing bar is a great visual reminder a track is about to end. The flashing bar will function regardless of which time mode the unit is in. **Note:** *When neither Total Remain nor Remain are showing in the LCD, the unit is showing the tracks' elapsed time.*

(32) SINGLE INDICATOR – This indicates the unit is in single play mode; the unit will play a single track and return to *Cue* mode.

(33) Pitch Meter – This meter displays the pitch percentage being applied to playback by the Pitch Slider (3). If the meter reads zero regardless of the Pitch Slider's (3) position, the Pitch (13) function is not activated.

(34) Total Remain Indicator – This indicator is in direct reference to the *Time Meter (36, 37, & 38)*. When the *Total Remain Indicator* is displayed in the LCD (2), the time defined will refer to the entire discs' remaining time. The time mode is changed by tapping on Time Button (9). The unit will indicate the elapsed time when neither the *Total Remain* or *Remain* indicators are showing.

(35) Remain Indicator – This indicator is in direct reference to the time meter (36, 37, & 38). When the *Remain Indicator* is displayed in the LCD (2), the time defined will refer to a single track's remaining time. The time mode is changed by tapping on *Time Button (9)*. The unit will indicate the elapsed time when neither the *Total Remain* or *Remain* indicators are showing.

(36) Frame Meter – This meter will display the elapsed time, total time, or frames. The displayed frames will be indirect reference to the current time mode.

(37) Seconds Meter – This meter will display the elapsed, total, or remaining time in seconds. The display time will be indirect reference to the current time mode.

(38) Minutes Meter – This meter will display the elapsed, total, or remaining time in minutes. The display time will be indirect reference to the current time mode.

(39) TRACK INDICATOR – This double digit indicator details a current track. The number displayed in the track indicator is a direct reference to a track being selected for programming or a track in play, pause, or cue mode.

BASIC OPERATIONS

OPENING AND CLOSING THE DISC TRAY

This is an electronic operation and can only work when the power is on. Press the Open/Close button (19) to open or close the disc tray. Pressing the Play/Pause button (3), will also automatically close the tray if it is open and immediately cue any CD that is in it. If the transport tray is left open for more than 60 seconds it will close automatically to prevent accidental damage to the transport. Again if a CD is left in the transport tray it will immediately cue to the first song. The disc tray cannot be opened during playback to prevent playback from being interrupted if the Open/Close button (19) is pressed accidentally. Stop playback, then press the Open/Close button (19).

LOADING DISCS

The device can play both 3 inch (8 cm) and 5 inch (12 cm) compact discs (CDs). Odd shaped and oval CD's are not compatible. When loading a CD into the unit, always hold the disc by its edges and place it in the disc tray. Never touch the signal surface (the glossy side).

When using 5 inch/12 cm discs, place the disc in the outer tray guides (Figure 8), and when using 3 inch/8 cm discs, place them securely in the inner guides (Figure 9).

Caution:

- Never insert any foreign objects in the disc tray.
- Never attempt to insert more than one disc in the disc tray at a time. Doing so may result in severe damage to the unit.
- Never force the transport tray open or closed when the power is off, as this may result in malfunction and damage the transport system.




Figure 8 (5 inch / 12 cm disk)




Figure 9 (3 inch / 8 cm disk)

SELECTING TRACKS

Select a desired track by using either of the two *Track Buttons (10)*. Tapping the *Track Buttons (10)* once will select either a higher or lower track. You may hold down the *Track Buttons (10)* to change tracks continuously at a higher speed. If you are using the *Track Buttons (10)* to select a new track during playback (a track already playing) the new track you selected will immediately begin playback as soon as the search operation is completed.

STARTING PLAYBACK

Insert an audio CD as described on page 20 (Loading Discs). Pressing the Play/Pause Button **(17)** with an audio CD inserted will immediately start playback. The point at which playback starts (Cue Point) will automatically be stored in the memory as Cue Point. The unit will return to this Cue Point (the point at which playback started) when the CUE Button **(18)** is pressed.

STOPPING PLAYBACK

Stopping playback will not stop the drive mechanism, but merely pause or cue the track. There are two ways to stop playback:

1. Press the Play/Pause button **(17)** during playback to pause at that point.
2. Press the CUE button **(18)** during playback to return the track to its last cue point.

PAUSING

Pausing temporarily stops playback. Pressing the Play/Pause Button **(17)** changes the operating mode between play and pause.

SETTING CUE POINTS

"Cueing" is the action of preparing for playback. The unit is designed to automatically cue at the first audible signal on the first track of a disc when a disc is inserted. If a track is selected before a disc is inserted, the unit will automatically cue to the first audible signal for the selected track.

You may press the IN button **(4)** on the fly (while the disc is playing). This will set a Cue Point without music interruption. Pressing the CUE Button **(18)** will now return you to the same point that you pressed the CUE Button **(18)**.

CHANGING THE TIME DISPLAY **(36, 37, 38)** / TIMEBAR **(39)**

The time may be displayed in three different modes; *Total Remain*, *Remain*, and *Elapsed*. During normal playback, pressing the Time button **(9)** will change the time display information **(36, 37, 38)** in the LCD **(2)**. The following is a breakdown of the time settings and their definitions:

- **Total Remain (34)** - details the time in the LCD (30, 29, 28) as the current CDs' total remaining time.
- **Remain (39)** - details the time in the LCD (36, 37, 38) as the current tracks' remaining running time.
- **Elapsed** - details the time in the LCD (36, 37, 38) as the current tracks' elapsed running time. **Note:** *The LCD will not display Elapsed, and neither the Remain nor the Total Remain indicators will be displayed in the LCD.*

TIME BAR INDICATOR

The time bar in the LCD (2) visually details the time defined in the Time Meter (36, 37, 38). This bar is also dependent on the selected time function *Remain* or *Total Remain*. This bar will begin to flash when 15 seconds of a track remain and will begin to rapidly flash when 3 seconds of a track remain. The flashing bar is a great visual reminder a track is about to end. The flashing bar will function regardless of which time mode the unit is in.

PITCH ADJUSTMENTS

This function will increase or decrease a track's playback speed or "pitch", this is not a momentary change as in "Pitch Bending" as described on page 23 (Pitch Bend). The maximum pitch percentage of the Pitch Slider (3) is +/-16%. The Pitch Slider (3) is used to decrease or increase the playback pitch. If the slider is moved up (towards the top of the unit), the pitch will decrease, if the slider is moved down (towards the bottom of the unit) the pitch will increase.

USING THE PITCH SLIDER PERCENTAGE SELECTOR (8)

You may choose a pitch operating range at any time. To change the operating range be sure the pitch function is turned on, see *Figure 10*.




Figure 10

The pitch percentage can be changed between +/-4%, +/-8%, and +/-16%. 4% will allow the least amount of pitch manipulation and 16% will allow the most amount of pitch manipulation. To adjust the different values, press the Pitch On/Off Button (13) and tap on the % Button (8) until your desired value is reached. The LED of the % Button (8) will start to glow; yellow for 4%, glowing green for 8%, or glowing red for 16%.

Activating the Pitch Slider (3)

To activate the pitch slider (3), turn the pitch function on.




Figure 11

Press the Pitch Button (13) to turn on the pitch function, when the pitch function is activated a LED will begin to glow. If the pitch function is not activated neither the Pitch Slider (3) nor the Pitch Bend Buttons (14) will function.

Using the Pitch Slider (3)

To use the Pitch Slider (3) slide the slider up and down. Down will increase the pitch and up will decrease the pitch.




Figure 12

PITCH BEND

This function will momentarily increase or decrease a tracks playback speed. There are two ways to operate this function with the (-) & (+) Pitch Buttons (14) or with the Jog Wheel (1). The maximum pitch bend percentage allowed is +/-16%. The pitch bend function will work in conjunction with the Pitch Slider (3) pitch setting.

Pitch Bend Buttons (14)

The (+) Pitch Bend button (14) will provide a speed bump and the (-) Pitch Bend button (14) will provide a slowdown. The maximum range of the Pitch Bend buttons is 16%. The extent to which the speed changes are proportionate to the amount of time the button is pressed. For example, if the (+) Pitch Bend button (14) is held down continuously, the disc speed will increase and will continue to increase until it reaches a maximum of 16% speed gain. When you release the (+) Pitch Bend button (14) the disc speed will automatically return to its previous speed.

(+) PITCH BEND BUTTON (14)

Holding down or tapping on the (+) Pitch Bend button (14) will provide a speed bump in the playback pitch.




Figure 13

(-) PITCH BEND BUTTON (14)

Holding down or tapping on the (-) Pitch Bend button (14) will provide a slowdown in the playback pitch.




Figure 14

JOG WHEEL (1)

The Jog Wheel (1) will temporarily bend the pitch if a track is in play mode.




Figure 15

Turning the wheel in a clockwise direction will increase your track pitch and turning the wheel in a counter-clockwise direction will slow your track pitch.

The speed you rotate the Jog Wheel (1) will determine pitch bend percentage.

CREATING AND PLAYING A LOOP

A loop is a sound loop that plays continuously. You can use this loop to create a dramatic effect in your mixing. This loop has no time limit and you could actually loop the entire length of disc.

Press Play/Pause button (17) to activate playback mode.




Figure 16

Press the IN button (4). This will set the starting point of the Seamless Loop (Figure 17).

The IN button LED will blink.




Figure 17

Press the OUT button (11) to set the ending point for your LOOP (Figure 18). The IN and OUT buttons will stay lit indicating a LOOP is playing. Press the OUT button again to cancel the Loop.




Figure 18

Press the ReLoop button (16) to reactivate the loop. Press the OUT button (11) to deactivate the loop.




Figure 19

Press the OUT button (11) again when you reach your new ending point (**Figure 18**).

- **For a shorter Loop:** Press the OUT button (11) at sooner point in the track (**Figure 18**).
- **For a longer Loop:** Press the OUT button (11) at later point in the track (**Figure 18**).

FLIP-FLOP (RELAY) CONNECTION AND SETUP

RELAY (FLIP-FLOP™)


This feature is a kind of “auto pilot“. Flip-Flop™ mode can only function with the both drives of the DCDPro-310 MKII. With Flip-Flop™ you can have one disc drive begin playback when the other ends. You can Flip Flop™ single tracks, or entire discs.

- Load disc drives with audio discs.
- Press the Relay button (**12**), the LED above the Relay button will light up letting you know that Flip-Flop™ mode has been activated. Press the SGL/CTN button (**7**) to choose between Single mode or Continuous mode.
- After they have both cued, press the Play/Pause button (**17**) on one of your drives to begin playback.
- If you have the CD player set to *Single* mode, the first CDs' single track will play and after it has ended the second CDs' track will immediately begin playback. If the player is set to *Continuous* mode, the first CD will play all the way through, and then after it has ended the second CD will start.
- FLIP FLOP™ will continue until you stop it or power is interrupted.
- To deactivate Flip-Flop™ mode, press the Relay button again.


BEFORE SWITCHING OFF THE POWER

- When you have finished using the CD unit, and before switching off the power, be sure that the disc holder has been closed with the OPEN/CLOSE button.
- Tray Protection: If tray is not closed after 60 seconds, it will close automatically and pause.

CAUTION: Do not forcibly close the disc holder when the power is off.



Do not switch off the power when the disc holder is open.



Switch off the power after the disc holder has been closed with the OPEN/CLOSE button.

Note: Do not switch off the power when the disc holder is open. Switch off the power after the disc holder has been closed with the Open/Close button.

COMPACT DISCS

PRECAUTIONS ON HANDLING COMPACT DISCS

Compact discs are constructed of the same types of plastic records are. To avoid severe damage to your valuable discs please observe the following guide lines. Following these guide lines will ensure long disc life.

- Do not allow fingerprints, oil or dust to get on the surface of the disc. If the disc is dirty, wipe it off with a soft dry cloth.
- Do not use benzene, thinner, water, record spray, electrostatic-proof chemicals, or silicone-treated cloths to clean discs.
- Always handle discs carefully to prevent damaging the surface; in particular when removing a disc from its jewel case.
- Do not bend the disc.
- Do not apply heat.
- Do not enlarge the hole in the center of the disc.
- Do not write on the label (printed side) with a hard tipped implement such as a pencil or ball point pen.
- Condensation will form if a disc is brought into a warm area from a colder one, such as outdoors in winter. Do not attempt to dry the disc with a hair dryer, etc.

PRECAUTION ON STORAGE

- After playing a disc, always unload it from the unit.
- Always store the compact disc in the jewel case, protecting from dirt or damage.

Do not place discs in the following areas:

- Areas exposed to direct sunlight for a considerable time.
- Areas subject to accumulation of dust or high humidity.
- Areas affected by heat from indoor heaters, etc.

ROHS – A GREAT CONTRIBUTION TO THE CONSERVATION OF ENVIRONMENT

The European Union has adopted a directive on the restriction / prohibition of the use of hazardous substances. This directive, referred to as ROHS, is a frequently discussed topic in the electronic industry.

It restricts, among other things, six materials: Lead (Pb), Mercury (Hg), hexavalent chromium (CR VI), cadmium (Cd), polybrominated biphenyls as flame retardant (PBB), polybrominated diphenyl, also a flame retardant (PBDE). The directive applies to nearly all electronic and electrical devices whose mode of operation involves electric or electromagnetic fields – in short: each kind of electronics we have around us in our households or at work.

As manufacturers of products of the brands of AMERICAN AUDIO, AMERICAN DJ, ELATION Professional and ACCLAIM Lighting, we are obligated to comply with the RoHS directive. Therefore, as early as two years prior to the directive coming into force, we started our search for alternative environmentally friendly materials and manufacturing processes.

Well before the RoHS directive took effect, all of our products were manufactured meeting the standards of the European Union. With regular audits and material tests we can still assure that the components we use are always RoHS-compliant and that the manufacturing process, as far as the state of technology allows, is environmentally friendly.

The ROHS directive is an important step to the protection of our environment. We, as manufacturers, feel obligated to make our contribution in this respect.

WEEE – WASTE OF ELECTRICAL AND ELECTRONIC EQUIPMENT

Every year thousands of tonnes of electronic components, which are harmful to the environment, end up at the waste disposals around the world. To ensure the best possible disposal or recovery of electronic components, the European Union has adopted the WEEE directive.

The WEEE-system (Waste of Electrical and Electronic Equipment) can be compared with the system of the “Green Spot”, which has been in use for several years. The manufactures have to make their contribution to the utilization of waste at the time they release the product. Money resources obtained by doing so will be applied to develop a common system of waste management. Thereby we can ensure professional and environmentally friendly scraping and recycling program.

As manufactures, we are part of the German system of EAR and we make our contribution towards it.

(Registration in Germany: DE41027552)

That means that products of AMERICAN DJ and AMERICAN AUDIO can be left in the collection points free of charge and they will be used in the recycling program. Products of ELATION Professional, which are used only by professionals, shall be handled by us. Please send Elation products directly to us at the end of their lifetime so that we can professionally dispose of them.

Like the above ROHS, the WEEE directive is an important contribution to the environment protection and we are glad to help to clean the environment with this disposal system.

We are happy to answer any of your inquiries and welcome your suggestions at:
info@americandj.eu

SPECIFICATIONS

GENERAL

Model:	American Audio® DCD-PRO310 MKII™ - Prof. Compact Disc Player
System:	Dual, CD Tray Loading, Digital Compact Disc Audio Player
Disc Type:	Standard compact discs (5 in / 12 cm and 3 in / 8 cm discs)
Dimensions:	Player Unit: 19" (W) x 3.49" (H) x 10" (D) 482mm (W) x 88.8mm (H) x 251mm (D) (without feet) Control Unit: 19"(W) x 3.49" (H) x 3.2" (D) 482mm (W) x 88.8mm (H) x 80mm (D) (without feet)
Installation:	Place on flat surface or mount in flat case
Weight:	15 Lbs. / 7kg
Power Supply:	AC 115v/230v, 50/60Hz AC 100V, 50/60Hz (Japan) AC 110V, 60Hz (Colombia) AC 120V, 60Hz (U.S.A. and Canada) AC 127V, 60Hz (Mexico) AC 220V, 50Hz (Chile and Argentina) AC 220V, 60Hz (Philippines and Korea) AC 230V, 50Hz (Europe, New Zealand, South Africa, Singapore) AC 240V, 50Hz (Australia and U.K.)
Power Consumption:	18W
Pitch Control Range:	+/-4%, +/-8%, +/-16%
Pitch Bend:	+/-4%, +/-8%, +/-16%
Pitch Accuracy:	0.1%
Environmental Conditions:	Operational temperature: 5 to 35°C (41 to 95°F)
Operational Humidity:	25 to 85% RH (non-condensation)
Storage Temperature:	-20 to 60°C (4 to 140°F)
Accessories:	Dual RCA Cable (for left and right channels) Control 1/8" miniplug type (3 feet)

AUDIO SECTION

Quantization:	16 bit linear per channel
Sampling Rate:	44.1 kHz at normal pitch
Over Sampling Rate:	8 times over sampling 1 bit D/A converter
D/A Conversion	16 bit
Frequency Response:	20Hz to 20KHz +/-0.4dB
Output Level:	2.0V +/- 1dB
Load Impedance:	47k ohm or more

AUDIO CHARACTERISTICS

(Test disc: TCD-782; LOAD=47Kohm):

Item	Nominal	Limit	Condition
Output level	2Vrms +/-0.5dB	2Vrms +/-1dB	1KHz,0dB
Channel balance	0.1dB	1dB	1KHz,0dB
Freq. Response	+/-0.4dB	+/-1.0dB	20Hz-20KHz, 0dB
De-emph. Response	+/-0.4/-0dB	+/-1dB	16KHz, -20dB
Ch. Sep. *2 (*1)	89dB	80dB	1KHz,0dB
T.H.D. + NOISE (*1)	0.01%	0.03%	1KHz,0dB
S/N ratio (IHF-A) (*2)	92dB	85dB	1KHz,0dB

Note: (*1) With 20 kHz low pass filter.

SEARCHING TIME

(Test disk: TCD-792)

Item	Nominal	Limit	Condition
Short access time	2 sec	4 sec	Play next track
Long access time	4 sec	6 sec	Track 1 => Track 20 / Track 20 -> Track 1
CD recover time	1 sec	2 sec	CD play interrupted by mechanical shock

PLAYABILITY

Item	Nominal	Limit	Condition
Interruption	1mm	0.7mm	TCD-725
Black dot	1mm	0.6mm	TCD-725
Finger prints	75um	65um	TCD-725
Eccentricity	140um	140um	TCD- 712, W/O TRACK JUMP
Vertical deviation	1mm	0.5mm	TCD- 731R

PICK-UP

System: Object lens drive system optical pick-up

Object Lens Drive System: 2 dimensional parallel drive

Tracking Detection: 3 spot beam detection

Optical Source: Semiconductor laser

Wave Length: 780nm



©American Audio®
A Division of the American DJ® Group of Companies
©American Audio® World Headquarters:
6122 S. Eastern Ave., Los Angeles, CA 90040 USA
Tel: 323-582-3322 Fax: 323-582-3311
Web: www.americanaudio.us E-mail: info@americanaudio.us