

## ADJ 12PX Hex/12PX Hex Pearl - DMX Traits & Values

CHANNEL MODE				DMX VALUES	DESCRIPTION
6-CH	7-CH	8-CH	12-CH		
1	1	1	1	000 - 255	<b>Red</b> , 0-100%
2	2	2	2	000 - 255	<b>Green</b> , 0-100%
3	3	3	3	000 - 255	<b>Blue</b> , 0-100%
4	4	4	4	000 - 255	<b>White</b> , 0-100%
5	5	5	5	000 - 255	<b>Amber</b> , 0-100%
6	6	6	6	000 - 255	<b>UV</b> , 0-100%
	7	7	7	000 - 255	<b>Master Dimmer</b>
					<b>Strobe</b>
				000 - 031	LED Off
				032 - 063	LED On
				064 - 095	Strobe, slow to fast
				096 - 127	LED On
				128 - 159	Pulse Strobe, slow to fast
				160 - 191	LED On
				192 - 223	Random Strobe, slow to fast
				224 - 255	LED On
			8		
		8	8		
			9	000 - 255	<b>Color Macros</b> , see <b>Color Macro Chart</b>
					<b>Programs</b>
				000 - 020	No function
				021 - 040	30 Color Change
				041 - 060	6 Color Change
				061 - 080	Color Fade
				081 - 100	Sound Active 30 Color Change
				101 - 120	Sound Active 6 Color Change
				121 - 140	Sound Active 6 Color Fade
				141 - 255	No function
			10		
			11		<b>Program Speed / Sensitivity</b>
				000	No function
				001 - 255	Speed Adjustment, slow to fast (when Ch 10 is set to 021 - 080) Sound Sensitivity, least to most (when Ch 10 is set to 081 - 140)
					<b>Dim Mode</b>
				000 - 020	Standard
				021 - 040	Stage
				041 - 060	TV
				061 - 080	Architectural
				081 - 100	Theatre
				101 - 255	Dimming Default to Display
			12		