

ADJ ENCORE Z7LP - DMX TRAITS

CHANNEL						DMX VALUE	FUNCTION
6CH	9CH	10CH	12CH	15CH	18CH		
1	1	1	1	1	1	000 - 255	Red , 0% to 100%
		2				000 - 255	Red Fine
2	2	3	2	2	2	000 - 255	Green , 0% to 100%
		4				000 - 255	Green Fine
3	3	5	3	3	3	000 - 255	Blue , 0% to 100%
		6				000 - 255	Blue Fine
4	4	7	4	4	4	000 - 255	Lime , 0% to 100%
		8				000 - 255	Lime Fine
			5	5	5	000 - 255	Color Macros , see Color Macros Chart section of this manual for details
			6	6	6	000 - 255	Color Temperature , 2700K to 6500K linear
							Color Temperature Macros
						000	Off
						001 - 054	2700K
			7	7	7	055 - 109	3200K
						110 - 164	4000K
						165 - 219	5600K
						220 - 255	6500K
							Shutter, Strobe
						000 - 031	LEDs Off
						032 - 063	LEDs On
						064 - 095	Strobe Effect, slow to fast
	5		8	8	8	096 - 127	LEDs On
						128 - 159	Pulse Effect in Sequences
						160 - 191	LEDs On
						192 - 223	Random Strobe Effect, slow to fast
						224 - 255	LEDs On
	6		9	9	9	000 - 255	Dimmer Intensity , 0% to 100%
	7		10	10	10	000 - 255	Dimmer Fine
5	8	9	11	11	11	000 - 255	Zoom Linear , minimum to maximum beam angle

CONTINUED ON NEXT PAGE

ADJ ENCORE Z7LP - DMX TRAITS

CHANNEL						DMX VALUES	FUNCTION
6CH	9CH	10CH	12CH	15CH	18CH		
6	9	10	12	12	12		Zoom Presets
						000 - 020	Normal (5°)
						021 - 040	Very Narrow Spot (6°)
						041 - 060	Narrow (10°)
						061 - 080	Medium Flood (30°)
						081 - 100	Wide Flood (40°)
						101 - 255	Very Wide Flood (50°)
					13		Auto Programs
						000 - 031	Off
						032 - 063	Auto Program 1
						064 - 095	Auto Program 2
						096 - 127	Auto Program 3
						128 - 159	Auto Program 4
						160 - 191	Auto Program 5
						192 - 223	Auto Program 6
224 - 255	Auto Program 7						
					14	000 - 255	Auto Programs Speed , slow to fast
					15	000 - 255	Auto Programs Fade , minimum to maximum
				13	16		Dim Mode
						000 - 020	Default to unit setting
						021 - 040	Standard
						041 - 060	Stage
						061 - 080	TV
						081 - 100	Architectural
						101 - 120	Theatre
						121 - 140	Stage 2
						141 - 160	Dim Speed, fast to slow (0.1s - 10s)
161 - 255	Default to unit setting						
				14	17		Dim Curves
						000 - 020	Square
						021 - 040	Linear
						041 - 060	Inv. Squa.
						061 - 080	S. Curve
081 - 255	No Function						

CONTINUED ON NEXT PAGE

ADJ ENCORE Z7LP - DMX TRAITS

CHANNEL						DMX VALUES	FUNCTION
6CH	9CH	10CH	12CH	15CH	18CH		
							<i>Refresh Rates</i>
						000 - 015	Default to unit setting
						016 - 030	900 Hz
						031 - 045	1000 Hz
						046 - 060	1100 Hz
						061 - 075	1200 Hz
						076 - 090	1300 Hz
						091 - 105	1400 Hz
				15	18	106 - 120	1500 Hz
						121 - 135	2500 Hz
						136 - 150	4000 Hz
						151 - 165	5000 Hz
						166 - 180	10000 Hz
						181 - 195	15000 Hz
						196 - 210	20000 Hz
						211 - 225	25000 Hz
						226 - 255	No Function