


# ELIMINATOR<sup>®</sup>

LIGHTING



## **BUBBLETRON EXL GO**

User Manual

©2024 ADJ Products, LLC all rights reserved. Information, specifications, diagrams, images, and instructions herein are subject to change without notice. Eliminator Lighting, ADJ Products, LLC logo and identifying product names and numbers herein are trademarks of ADJ Products, LLC. Copyright protection claimed includes all forms and matters of copyrightable materials and information now allowed by statutory or judicial law or hereinafter granted. Product names used in this document may be trademarks or registered trademarks of their respective companies and are hereby acknowledged. All non-ADJ Products, LLC brands and product names are trademarks or registered trademarks of their respective companies.

**ADJ Products, LLC** and all affiliated companies hereby disclaim any and all liabilities for property, equipment, building, and electrical damages, injuries to any persons, and direct or indirect economic loss associated with the use or reliance of any information contained within this document, and/or as a result of the improper, unsafe, insufficient and negligent assembly, installation, rigging, and operation of this product.

#### **ADJ PRODUCTS LLC World Headquarters**

6122 S. Eastern Ave. | Los Angeles, CA 90040 USA

Tel: 800-322-6337 | Fax: 323-582-2941 | [www.adj.com](http://www.adj.com) | [lsupport@adj.com](mailto:lsupport@adj.com)

#### **ADJ Supply Europe B.V.**

Junostraat 2 | 6468 EW Kerkrade | Netherlands

Tel: +31 45 546 85 00 | Fax: +31 45 546 85 99 | [www.adj.eu](http://www.adj.eu) | [info@adj.eu](mailto:info@adj.eu)

#### Europe Energy Saving Notice

Energy Saving Matters (EuP 2009/125/EC)

Saving electric energy is a key to help protecting the environment. Please turn off all electrical products when they are not in use. To avoid power consumption in idle mode, disconnect all electrical equipment from power when not in use. Thank you!

#### **DOCUMENT VERSION**



Due to additional product features and/or enhancements, an updated version of this document may be available online.

Please check <https://www.adj.com/eliminator-lighting> for the latest revision/update of this manual before beginning installation and/or programming.

Date	Document Version	Software Version >	DMX Channel Mode	Notes
12/22/23	1.0	N/A	N/A	Initial release
02/16/24	1.1	N/A	N/A	Updated Battery Recharging, Specifications
03/15/24	1.2	N/A	N/A	Updated Dimensional Drawings, Specifications

# CONTENTS

<b>General Information</b>	<b>4</b>
<b>Limited Warranty (USA Only)</b>	<b>5</b>
<b>Safety Guidelines   Battery Precautions</b>	<b>6</b>
<b>Overview</b>	<b>7</b>
<b>Operating Instructions</b>	<b>8</b>
<b>Battery Replacement</b>	<b>9</b>
<b>Battery Recharging   Cleaning   Dimensional Drawings</b>	<b>10</b>
<b>Specifications</b>	<b>11</b>

# GENERAL INFORMATION

## INTRODUCTION

Please read and understand all instructions in this manual carefully and thoroughly before attempting to operate these products. These instructions contain important safety and use information.

## UNPACKING

The products in this kit have been thoroughly tested and have been shipped in perfect operating condition. Carefully check the shipping carton for damage that may have occurred during shipping. If the carton appears to be damaged, carefully inspect each unit included for damage and be sure all accessories necessary to operate the units have arrived intact. In the event damage has been found or parts are missing, please contact our customer support team for further instructions. Please do not return this kit to your dealer without first contacting customer support at the number listed below. Please do not discard the shipping carton in the trash. Please recycle whenever possible.

## FEATURES

- Portable high output bubble machine
- Creates hundreds of bubbles per minute
- Extra-large, durable plastic casing with EZ-Access front fluid tank
- Large, dual high velocity, high output fans
- ON/OFF switch on rear of unit
- Carrying handle
- Compatible with ADJ Bubble Juice (recommended) as well as most types of bubble liquid.
- Includes Z-LC3 Wired Remote Control
- BUBXL-WR Wireless Remote Control sold separately
- Battery Operation

## CUSTOMER SUPPORT

Tel: (323) 213-4592 | Fax: (323) 582-2941

[www.adj.com](http://www.adj.com) | [support@eliminatorlighting.com](mailto:support@eliminatorlighting.com)

**Warning!** To prevent or reduce the risk of electrical shock or fire, do not expose this unit to rain or moisture.

**Caution!** There are no user serviceable parts inside this unit. Do not attempt any repairs yourself, as doing so will void your manufacturer's warranty. In the event that your unit requires service, please contact Eliminator Lighting for assistance.

## WARRANTY RETURNS

All returned service items whether under warranty or not, must be freight pre-paid and accompany a return authorization (R.A.) number. The R.A. number must be clearly written on the outside of the return package. A brief description of the problem as well as the R.A. number must also be written down on a piece of paper and included in the shipping container. If the unit is under warranty, you must provide a copy of your proof of purchase invoice. Items returned without a R.A. number clearly marked on the outside of the package will be refused and returned at customer's expense. You may obtain a R.A. number by contacting customer support.

## LIMITED WARRANTY (USA ONLY)

- A. Eliminator Lighting, an ADJ Products, LLC brand, hereby warrants, to the original purchaser, Eliminator Lighting products to be free of manufacturing defects in material and workmanship for a prescribed period from the date of purchase (see specific warranty period on reverse). This warranty shall be valid only if the product is purchased within the United States of America, including possessions and territories. It is the owner's responsibility to establish the date and place of purchase by acceptable evidence, at the time service is sought.
- B. For warranty service, you must obtain a Return Authorization number (RA#) before sending back the product—please contact ADJ Products, LLC Service Department at 800-322-6337. Send the product only to the Eliminator Lighting factory. All shipping charges must be pre-paid. If the requested repairs or service (including parts replacement) are within the terms of this warranty, Eliminator Lighting will pay return shipping charges only to a designated point within the United States. If the entire instrument is sent, it must be shipped in its original package. No accessories should be shipped with the product. If any accessories are shipped with the product, Eliminator Lighting shall have no liability whatsoever for loss of or damage to any such accessories, or for the safe return thereof.
- C. This warranty is void if the serial number has been altered or removed; if the product is modified in any manner which Eliminator Lighting concludes, after inspection, affects the reliability of the product, if the product has been repaired or service by anyone other than ADJ Products, LLC factory unless prior written authorization was issued to purchaser by Eliminator Lighting; if the product is damaged because not properly maintained as set forth in the instruction manual.
- D. This is not a service contract, and this warranty does not include maintenance, cleaning or periodic check up. During the period specified above, Eliminator Lighting will replace defective parts at its expense with new or refurbished parts, and will absorb all expenses for warranty service and repair labor by reason of defects in material or workmanship. The sole responsibility of Eliminator Lighting under this warranty shall be limited to the repair of the product, or replacement thereof, including parts, at the sole discretion of Eliminator Lighting. All products covered by this warranty were manufactured after August 15, 2012, and bear identifying marks to that effect.
- E. Eliminator Lighting reserves the right to make changes in design and/or improvements upon its products without any obligation to include these changes in any products theretofore manufactured.
- F. No warranty, whether expressed or implied, is given or made with respect to any accessory supplied with products described above. Except to the extent prohibited by applicable law, all implied warranties made by Eliminator Lighting in connection with this product, including warranties of merchantability or fitness, are limited in duration to the warranty period set forth above. And no warranties, whether expressed or implied, including warranties of merchantability or fitness, shall apply to this product after said period has expired. The consumer's and/or Dealer's sole remedy shall be such repair or replacement as is expressly provided above; and under no circumstances shall Eliminator Lighting be liable for any loss or damage, direct or consequential, arising out of the use of, or inability to use, this product.
- G. This warranty is the only written warranty applicable to Eliminator Lighting products and supersedes all prior warranties and written descriptions of warranty terms and conditions heretofore published.

### MANUFACTURER'S LIMITED WARRANTY PERIODS

- **Non L.E.D. Eliminator Lighting products** = 1-year (365 days) Limited Warranty (Such as: Special Effect Lighting, Intelligent Lighting, UV lighting, Strobes, Fog Machines, Bubble Machines, Mirror Balls, Par Cans, Trussing, Lighting Stands etc., excluding lamps)
- **L.E.D. Eliminator Lighting Products** = 2-year (730 days) Limited Warranty (excluding batteries which have a 180 day limited warranty). Note: 2 Year Warranty only applies to purchases within the United States.
- **Eliminator Laser Products** = 1 Year (365 Days) Limited Warranty (excluding laser diodes which have a 6 month limited warranty)

# SAFETY GUIDELINES


## For Your Own Personal Safety, Please Read and Understand This Manual

- To reduce the risk of electrical shock or fire, do not expose this unit to rain or moisture.
- Do not spill water or other liquids into or on to your unit.
- Be sure that the local power outlet matches that of the required voltage for your unit.
- Do not attempt to operate this unit if the power cord has been frayed or broken.
- Do not attempt to remove or break off the ground prong from the electrical cord. This prong is used to reduce the risk of electrical shock and fire in case of an internal short.
- Disconnect from main power before making any type of connection.
- Do not remove the cover under for any reason. There are no user serviceable parts inside.
- Never operate this unit with the cover removed.
- Always be sure to place this unit in an area that will allow proper ventilation. Allow about 6" (15cm) between this device and a wall.
- Do not attempt to operate this unit if it has been damaged in any way.
- This unit is intended for indoor use only, and use of this product outdoors voids all warranties.
- Always mount this unit in a safe and stable manner.
- Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles and the point where they exit from the appliance.
- The fixture should be cleaned only as recommended by the manufacturer.
- This fixture should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
- The fixture should be serviced by qualified service personnel when:
  - A. Objects have fallen, or liquid has been spilled into the appliance.
  - B. The appliance has been exposed to rain or water.
  - C. The appliance does not appear to operate normally or exhibits a marked change in performance.

# BATTERY PRECAUTIONS

- Never leave the device unattended when charging the batteries.
- If at any time you notice smoke, heat, or an abnormal odor, discontinue charging immediately. Disconnect the power supply immediately and contact a qualified technician.
- Exercise extreme caution if battery leakage is observed, as these chemicals can react with the surrounding air and ignite a fire.
- Never store or charge battery pack inside of a vehicle or in extreme temperatures, as this can result in a fire.
- Never transport or store the battery back in a high temperature environment for extended periods of time.

# OVERVIEW



# OPERATING INSTRUCTIONS

## Filling the Tray Reservoir:

1. Place the Bubbletron EXL Go on a flat level surface.
2. The bubble juice tray is located in the front of the machine. Fill the tray using premium ADJ® brand bubble juice. Make sure not to fill the tray above the designated fill line, as doing so will result in damage to the machine. After the usage, please empty the remaining juice to prevent damage as well.


## Operation:

With the unit on a flat surface and with the tray filled, flip the power switch to the “ON” position and watch the bubbles come out by the hundreds. Be sure the unit remains in a level position in order to avoid accidental leakage.

## Remote Operation:

The unit may be used with the (included) BUBGO-WR Wireless Remote Control.

1. With the power switch in the “OFF” position, plug the remote control into the unit.
2. Push the power button on the remote to the “ON” position, main power will be indicated by a glowing red LED above the remote power button.



# BATTERY REPLACEMENT

1. Remove the two central screws located on each side of the control panel, then pull the panel straight out. The battery is integrated into the control panel module, and they should be replaced as a single unit.

**BATTERY REMOVAL SCREWS**



2. Locate and disconnect the wire connector on the back side of the battery pack. Fully remove the old battery from its slot, and install a replacement by reversing these steps.




## BATTERY RECHARGING

To recharge the battery, plug the included power supply into the power input socket on the rear of the unit, then connect to a matching power supply. A red LED on the power supply will illuminate to indicate that the unit is charging. A green LED will illuminate when the unit has reached full charge. Estimated time to reach full charge is approximately 4 hours.

## CLEANING

The frequency of cleaning depends on the environment in which the device operates in: damp, smoky or particularly dirty environments can cause greater accumulation of dirt and or debris in the tank. Clean the external housing of the fixture and the tank at least periodically with a soft cloth to avoid dirt/debris accumulation. NEVER use alcohol, solvents, or ammonia-based cleaners.

## DIMENSIONAL DRAWINGS



# SPECIFICATIONS

## Features:

- Battery powered portable high output bubble machine
- Quadruple bubble wand creates hundreds of bubbles per minute
- Extra-large, durable plastic casing with EZ-Access front fluid tank
- Unique dual fan system that push bubbles up in the air so they can travel further
- Battery life indicator on rear of unit
- ON/OFF switch on rear of unit
- Carrying handle
- Includes BUBGO-WR Wireless Remote Control

## Fluid Tank:

- Tank Capacity: 2 Liter
- Fluid Consumption Rate: 16ml/ per minute

## Battery:

- Battery Capacity: 4.0Ah
- Battery Operating Time (full power): 3 hours
- Battery Charging Time: (per cycle): 4 hours

## Electrical:

- Power Consumption: 15W @ 120V
- Voltage: AC 100-240V, 50/60Hz (charger) DC 12V, 1000 mA

## Dimensions / Weight:

- Dimensions (LxWxH): 363.6mm x 266 x 277.9mm
- Weight: 9.7 lbs. / 4.4 kgs.

