# ADJ SABER SPOT UV - DMX TRAITS

| CHANNEL | | | DMX VALUES | FUNCTION |
|---|---|---|---|---|
| 1CH | 2CH | 4CH | | |
| 1 | 1 | 1 | 000–255 | **UV Intensity** (0–100%) |
| | | 2 | 000–255 | **UV Fine** (0–100%) |
| | | | | **Strobe** |
| | | | 000–031 | Strobe – Off |
| | | | 032–063 | Strobe – On |
| | | | 064–095 | Strobe – Slow → Fast |
| | 2 | 3 | 096–127 | Strobe – On |
| | | | 128–159 | Pulse Strobe |
| | | | 160–191 | Strobe – On |
| | | | 192–223 | Random Strobe |
| | | | 224–255 | Strobe – On |
| | | | | **Dimmer Delay Mode** |
| | | | 000–020 | Dimmer Curve – Standard |
| | | | 021–040 | Dimmer Curve – Stage |
| | | 4 | 041–060 | Dimmer Curve – TV |
| | | | 061–080 | Dimmer Curve – Architectural |
| | | | 081–100 | Dimmer Curve – Theatre |
| | | | 101–255 | Dimmer Curve – Controlled by Menu |