Update Procedure
SDJ1

**Please contact service@americandj.eu for the latest firmware.
CAUTION when running an update never: disconnect power supply, eject SD Card or switch OFF SDJ1.
This can cause permanent damage to the SDJ1, warranty will be void.**

1. Power ON SDJ1
2. Check the SDJ1 software version by entering the Preset menu (press and hold the TIME button and turning the Track knob)
3. In the Preset Menu will be shown *Vxx.xx* (control.buffer), update only when the downloaded files are newer
4. Save the downloaded binary file(s) (from www.americandj.eu) on an **empty** SD Card
5. Insert SD Card into Slot SD1
6. Wait until update is Complete
7. Power OFF SDJ1 by disconnecting power supply
8. Check software versions if update succeeded

NOTES:
- When an update fails, please check the software versions saved on the SD Card, they must be **newer** then the actual software versions of the SDJ1.
- The SDJ1 has a flash recovery feature, when the SD Card has been ejected or power has been disconnected or switched off, while running an update. Please run the update procedure again.